

---

# **INSTRUCTION MANUAL**

## **HUMIDITY TEMPERATURE TRANSMITTER**

**TYPE RS485**

**JXBS-3001-TH**

**VER1.1**

---

# I BRIEF INTRODUCTION

## 1.1 Product Overview

This product adopts high sensitivity photosensitive probe, the signal is stable and the precision is high. It has the characteristics of wide measurement range, good linear degree, good waterproof performance, convenient use, easy installation and long transmission distance.

## 1.2 Primary Parameters

---

| PARAMETERS                      | TECHNICAL SPECIFICATIONS |
|---------------------------------|--------------------------|
| POWER SUPPLY                    | 12-24V DC                |
| POWER                           | 0.4W                     |
| OUTPUT SIGNAL                   | RS485                    |
| RESPONSE TIME                   | ≤15S                     |
| LONG-TERM STABLE TEMPERATURE    | ≤0.1°C/year              |
| LONG-TERM STABILITY OF HUMIDITY | ≤1%y                     |
| TEMPERATURE RANGE               | -40°C-80°C               |
| HUMIDITY RANGE                  | 0-100%RH                 |
| TEMPERATURE RESOLUTION          | 0.1°C                    |
| HUMIDITY RESOLUTION             | 0.1%RH                   |
| POWER CONSUMPTION               | ≤0.15W(@12V DC , 25°C)   |

WORKING PRESSURE RANGE

0.9-1.1atm

### 1.3 Probe Parameters and Selection

| PRODUCT TYPE | PROBE TYPE | TEMPERATURE ACCURACY      | HUMIDITY ACCURACY    |
|--------------|------------|---------------------------|----------------------|
| -S20         | SHT20      | $\pm 0.3^{\circ}\text{C}$ | $\pm 3\text{-}7\%$   |
| -S30         | SHT30      | $\pm 0.3^{\circ}\text{C}$ | $\pm 2\text{-}4.5\%$ |
| -S31         | SHT31      | $\pm 0.3^{\circ}\text{C}$ | $\pm 2\%$            |
| -S75         | SHT75      | $\pm 0.3^{\circ}\text{C}$ | $\pm 1.5\text{-}3\%$ |

### 1.4 Temperature Parameters (-S20)

| CONTENT             | Minimum | Typical value | Maximum  | Unit                           |
|---------------------|---------|---------------|----------|--------------------------------|
| Resolution (14bit)  | -       | 0.01          | -        | $^{\circ}\text{C}$             |
| Linear deviation    | -       | $\pm 0.3$     | Figure 1 | $^{\circ}\text{C}$             |
| Repeatability       | -       | $\pm 0.1$     | -        | $^{\circ}\text{C}$             |
| The scope of work   | -40     | -             | 125      | $^{\circ}\text{C}$             |
| Response time (63%) | 5       | -             | 30       | second                         |
| Long-term drift     | -       | $<0.04$       | -        | $^{\circ}\text{C}/\text{year}$ |




Figure 1 Temperature measurement accuracy at different temperatures

As shown in the above table, the maximum deviation is within  $\pm 0.5$  in the range of 5-60 degrees Celsius, and the deviation increases with less than 0 degrees Celsius and greater than 60 degrees Celsius.

### 1.5 Humidity Parameter (-S20)

| CONTENT             | Minimum | Typical value | Maximum  | Unit      |
|---------------------|---------|---------------|----------|-----------|
| Resolution (12bit)  | -       | 0.04          | -        | %RH       |
| Linear deviation    | -       | $\pm 3.0$     | Figure 2 | %RH       |
| Repeatability       | -       | $\pm 0.1$     | -        | %RH       |
| The scope of work   | 0       | -             | 100      | %RH       |
| Response time (63%) | -       | 8             | -        | second    |
| Long-term drift     | -       | <0.5          | -        | %RH /year |
| Hysteresis          | -       | $\pm 1$       | -        | %RH       |
| Non-linearity       | -       | <0.1          | -        | %RH       |




Figure 2 Humidity measurement accuracy under different humidity conditions

As shown in the above table, the deviation increases with a typical deviation of  $\pm 3\%$  in the 20-80% RH range, less than 20%, and greater than 80% humidity.

---

## 1.6 Influence of temperature on humidity measurement (-S20)

Figure 2 describes the effects of different humidity conditions on the humidity measurement. The following table describes the effects of different temperatures on the humidity measurement accuracy.





Figure 3 Relative humidity at different temperatures

As shown in the above table, in the range of 15 to 55 degrees Celsius and 30 to 80 degrees of humidity, the accuracy of humidity is the highest, which is  $\pm 4.5\%$ . In other cases, the humidity increases.

## 1.7 System frame Diagram



**FIGURE 4 SINGLE-ENDED**




FIGURE 5 MUTIPLE-ENDED

## II HARDWARE CONNECTIONS

### 2.1 CHECKING BEFORE INSTALLATION

Check the list of devices before installation:

TABLE 1 List of Devices

---


| Name                             | Number |
|----------------------------------|--------|
| THE SENSOR DEVICE                | 1      |
| 12V POWER ADAPTER (Optional)     | 1      |
| WARRANTY CARD / CERTIFICATE      | 1      |
| THE USB TO 485 DEVICE (Optional) | 1      |

---

## 2.2 Interface Description

The power interface is wide voltage input 12-24V. When connecting the 485 signal cable, note that the A/B lines cannot be reversed. The addresses of multiple devices on the bus cannot conflict.

### 2.2.1 Economic Sensor Wiring



**FIGURE 6 PHYSICAL PICTURE**

**TABLE 2 Wiring Sequence**

---


| Line Color | Description |
|------------|-------------|
|------------|-------------|



|                      |       |                                     |
|----------------------|-------|-------------------------------------|
| <b>Power</b>         | VCC   | Power supply Positive ( 12-24V DC ) |
|                      | GND   | Power supply Negative               |
| <b>Communication</b> | 485-A | 485-A                               |
|                      | 485-B | 485-B                               |

Wiring method: After loosening the screw, insert the wire into the crimping hole from the terminal, and then tighten the screw to lock the wiring material.

### 2.2.2 LCD display shell wiring



**FIGURE 7 PHYSICAL PICTURE**


**TABLE 3 Wiring Sequence**

| NO. | Instructions                    | NO. | Instructions |
|-----|---------------------------------|-----|--------------|
| 1   | Power supply Positive (12-24VC) | 5   | 485-A        |
| 2   | Power supply Negative           | 6   | 485-B        |
| 7   | Sensor Power supply Positive    | 3   | SCL          |
| 8   | Sensor Power supply Negative    | 4   | SDA          |

Note: When the sensor is built in, 3/4/7/8 is idle.

Use a screwdriver to press down on the yellow buckle. Insert the wire into the crimping hole and release the yellow buckle to lock the wire.

### 2.2.3 External Probe Sensor Wiring



**FIGURE 8 PHYSICAL PICTURE**

**TABLE 4 Wiring Sequence**

|                      | Line Color | Description                         |
|----------------------|------------|-------------------------------------|
| <b>Power</b>         | Brown      | Power supply Positive ( 12-24V DC ) |
|                      | Black      | Power supply Negative               |
| <b>Communication</b> | Yellow     | 485-A                               |
|                      | Blue       | 485-B                               |

Precautions: Please take care not to take the wrong line sequence, the wrong wiring will cause the equipment to burn.


---

The factory default is to provide 0.6 meters long wire rods. Customers can extend the wire rods as required or sequentially.



Note that there are no yellow lines in the wire sequences that may be provided in some factory batches, in which case the gray line is equivalent to replacing the yellow line.

## 2.3 Installation

The economical version of the sensor is in the form of a standard rail mount, which snaps the back side of the sensor onto the rail.



The 86-shell wall-mounted large-screen sensor adopts the installation form of the inverted hoist hole, and the customer can mount the screw with a distance of 60mm.



The wall-mounted king-shaped shell is a wall-mounted installation. The installation holes are located at the middle positions on both sides of the device. The installation aperture is less than 4mm, and the hole distance is 105mm. It can be installed using a 3mm self-tapping screw.

## III CONFIGURATION TOOL INSTALLATION AND USE


We provide **CONFIGURATION TOOL** , which can be easily used to test our sensor device.

### 3.1 Sensor Access Computer

---

Transmitter can be connected to PC with the RS485 to USB adapter. You can check the COM port number through Device Manager (right click My Computer).

### 3.2 How To Use Configuration Tool



Please note that this software can only test one device at the same time. After connecting the physical device, click the **CONNECT** button to read the information. In the UNCONNECT state, you can modify BAUD and ADDR in COMMUNICATION SETTINGS.

Under the software, different check boxes can be selected according to different situations. For example, you can choose the GAS option to test the RS485 OXYGEN SENSOR , you can choose the NORMAL option to test the RS485 TEMPERATURE AND HUMIDITY SENSOR .

## IV COMMUNICATION PROTOCOL

---

## 4.1 Communication Basic Parameters

**TABLE 5 Communication Basic Parameters**

---

| <b>PARAMETERS</b> | <b>CONTENT</b>  |
|-------------------|---|
| Protocol          | Modbus RTU  |
| Data bits         | 8 bit   |
| Parity bit        | No  |
| Stop bit          | 1 bit   |
| Error checking    | CRC (redundant loop code)   |
| Baud rate         | 2400 bps/ 4800 bps/ 9600 bps can be set<br>factory defaults to 9600 bps |

---

For more information about **MODBUS RTU** please visit the website "[www.modbus.org](http://www.modbus.org)".

## 4.2 Register Address

---

| <b>Register Address</b> | <b>Plc Configuration Address</b> | <b>Content</b>             | <b>Operation</b> |
|-------------------------|----------------------------------|----------------------------|------------------|
| 0000H                   | 40001                            | Humidity(unit 0.1%RH)      | Read-Only        |
| 0001H                   | 40002                            | Temperature(unit 0.1°C)    | Read-Only        |
| 0100H                   | 40101                            | Device Address (0-252)     | R/W              |
| 0101H                   | 40102                            | Baud Rate (2400/4800/9600) | R/W              |

---

**TABLE 6 Register Address**

---

## 4.3 Communication example

### 4.3.1 Read Device Address 0x01's Soil Temperature And Humidity

**TABLE 7 Inquiry Frame**

| Address Code | Function Code | Start Address | Data Length | CRC_L | CRC_H |
|--------------|---------------|---------------|-------------|-------|-------|
| 0x01         | 0x03          | 0x00,0x00     | 0x00,0x02   | 0xC4  | 0x0B  |

**TABLE 8 Answer Frames**

| Address Code | Function Code | Number Of Valid Bytes | Humidity Value | Temperature Value | CRC_L | CRC_H |
|--------------|---------------|-----------------------|----------------|-------------------|-------|-------|
| 0x01         | 0x03          | 0x04                  | 0x02           | 0xFF              | 0x5A  | 0x3D  |
|              |               |                       | 0x92           | 0x9B              |       |       |

Temperature:

FF9BH ( hexadecimal ) = -101 => temperature = -10.1°C

Humidity:

292H( hexadecimal ) = 658 => humidity = 65.8%RH